


Functions and Features

• Receiving frequency

Area	Band	Receiving Frequency Range	FM (MHz) Others (kHz)	Reference Frequency (kHz)	Step (kHz)	IF FM (MHz) Others (kHz)	Diode Matrix B ₂ B ₁ B ₀
Japan	FM	76.0 to 90.0	50	50	100	-10.7	1 0 0
	MW	531 to 1611 (531 to 1629)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
USA	FM	87.9 to 107.9	50	50	200/100	10.7	0 0 0
	MW	530 to 1610 (530 to 1720)	10 (10)	10 (10)	10 (10)	450 (↑)	
	FM	87.9 to 107.9	50	50	200/100	10.7	1 1 1
	MW	522 to 1611 (522 to 1719)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
EUROPE	FM	87.50 to 108.00	25	25	50	10.7	0 0 1
	MW	531 to 1602 (522 to 1611)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
	LW	153 to 281 (146 to 290)	1 (1)	1 (1)	1 (1)	450/468 (↑)	
	FM	87.50 to 108.00	25	25	50	10.7	0 1 0
	MW	531 to 1602 (522 to 1611)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
	LW	153 to 281 (146 to 290)	1 (1)	1 (1)	1 (1)	450/468 (↑)	
	SW	SW1 5800 to 7300 SW2 9500 to 18000	5	5	5	450	
	FM	87.50 to 108.00	25	25	50	10.7	0 1 1
	MW	531 to 1602 (522 to 1611)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
	LW	153 to 281 (146 to 290)	1 (1)	1 (1)	1 (1)	450/468 (↑)	
SW	SW1 3200 to 7300 SW2 9500 to 18000	5 5	5 5	5 5	450 ↑		
S.AFRICA	FM	87.50 to 108.00	25	25	50	-10.7	1 1 0
	MW	531 to 1602 (522 to 1611)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
	LW	153 to 281 (146 to 290)	1 (1)	1 (1)	1 (1)	450/468 (↑)	
	FM	87.50 to 108.00	25	25	50	-10.7	1 0 1
	MW	531 to 1602 (522 to 1611)	9 (9)	9 (9)	9 (9)	450/468 (↑)	
LW	153 to 281 (146 to 290)	1 (1)	1 (1)	1 (1)	450/468 (↑)		
SW	SW1 5800 to 7300 SW2 9500 to 18000	5	5	5	450		

- Note) 1. A frequency in () is selected by using diode matrix “SHIFT”.
 2. The presence or absence of LW and U.S.A. 200/100 are selected by using diode matrix “LW200”.
 3. AM IF450/468 is selected by using diode matrix.

• Tuning method (Sawtooth wave mode : )

- Manual up/down
- Auto up/down
- Preset call by 8-button method

• Preset memory

- FM: Mode 1 8 channels
- Mode 2 8 channels
- AM : (MW+LW+SW)
- No distinction between mode 1 and mode 2 8 channels

24 channels in all

• Auto preset scan

• Timer function

- Timer Causes turn-ON mode only. Sleep timer (Set to the nearest 10 minutes).
- Clock 12/24hr mode 12hr : Japan, USA
 24hr : Europe, South Africa

• Usable with remote control

The LC7461M-8103 is used.

• Usable with electronic volume control : 7-dot LED (using the LB1417) display available.

The LC7535 is used.

• Usable with the function switch : LCD display and LED (using the MLC74HC375) display available.

The LC7821 (N) is used.


Continued on next page.

LC7230-8272

Continued from preceding page.

- On-chip LCD driver : 1/2 duty 1/2 bias frame frequency 100Hz
- Single 5V supply
- Package : QIP80A

Pin Assignment



Top view

Specifications

Absolute Maximum Ratings at $T_a = 25^\circ\text{C}$, $V_{SS}=0\text{V}$

Parameter	Symbol	Conditions	Ratings	Unit
Maximum supply voltage	$V_{DD\text{ max}}$		-0.3 to +6.5	V
Input voltage	V_{IN1}	INT, RES, SNS, \overline{SD} , REMO, STEREO, K5, K4	-0.3 to +6.5	V
	V_{IN2}	HOLD	-0.3 to +13	V
	V_{IN3}	Inputs other than V_{IN1} , V_{IN2}	-0.3 to $V_{DD}+0.3$	V
Output voltage	V_{OUT1}	VOL, FM, MW, LW	-0.3 to +15	V
	V_{OUT2}	Outputs other than V_{OUT1}	-0.3 to $V_{DD}+0.3$	V
Output current	I_{OUT1}	NARROW, PWROUT, AMUTE, STB, VOL, FM, MW, LW	0 to 5	mA
	I_{OUT2}	CE, DO, CLK, IFCNT, SW1/VU, SW2/VD, MO/ST, MUTE	0 to 3	mA
	I_{OUT3}	T0 to T7	0 to 1	mA
Allowable power dissipation	$P_d\text{ max}$	$T_a=-40\text{ to }+85^\circ\text{C}$	400	mW
Operating temperature	T_{opr}		-40 to +85	$^\circ\text{C}$
Storage temperature	T_{stg}		-45 to +125	$^\circ\text{C}$

Recommended Operating Conditions at $T_a = -40\text{ to }+85^\circ\text{C}$, $V_{DD}=3.5\text{ to }5.5\text{V}$

Parameter	Symbol	Conditions	Ratings			Unit
			min	typ	max	
Supply voltage	V_{DD1}	PLL operating mode *1	4.5		5.5	V
	V_{DD2}	CLOCK operating mode, PLL stopped *2	3.5		5.5	V
	V_{DD3}	Memory hold *3	1.3		5.5	V
Input high-level voltage	V_{IH1}	REMO, STEREO, K5, K4	$0.7V_{DD}$		5.5	V
	V_{IH2}	RES, INT	$0.8V_{DD}$		5.5	V
	V_{IH3}	SNS	2.5		5.5	V
	V_{IH4}	K0, K1, K2, K3	$0.6V_{DD}$		V_{DD}	V
	V_{IH5}	CE, DO, CLK, IFCNT, SW1/VU, SW2/VD, MO/ST, MUTE	$0.7V_{DD}$		V_{DD}	V
	V_{IH6}	HOLD	$0.8V_{DD}$		8.0	V

Continued on next page.

LC7230-8272

Continued from preceding page.

Parameter	Symbol	Conditions	Ratings			Unit
			min	typ	max	
Input low-level voltage	V _{IL1}	REMO, STEREO, K5, K4	0		0.3V _{DD}	V
	V _{IL2}	RES, INT, HOLD	0		0.2V _{DD}	V
	V _{IL3}	SNS	0		1.3	V
	V _{IL4}	K0, K1, K2, K3	0		0.2V _{DD}	V
	V _{IL5}	CE, DO, CLK, IFCNT, SW1/VU, SW2/VD, MO/ST, MUTE	0		0.3V _{DD}	V
Input frequency	f _{IN1}	XIN	4.0	4.5	5.0	MHz
	f _{IN2}	FMIN, V _{IN2} , V _{DD1}	10		130	MHz
	f _{IN3}	AMIN (MW, LW mode), V _{IN4} , V _{DD1}	0.5		10	MHz
	f _{IN4}	AMIN (SW mode), V _{IN5} , V _{DD1}	2.0		40	MHz
	f _{IN5}	HCTR (FMIF), V _{IN6} , V _{DD1}	0.4		12	MHz
	f _{IN6}	LCTR (AMIF), V _{IN7} , V _{DD1}	100		500	kHz
Input amplitude	V _{IN1}	XIN	0.50		1.5	Vrms
	V _{IN2}	FMIN	0.10		1.5	Vrms
	V _{IN3, 4}	AMIN (MW, LW mode)	0.10		1.5	Vrms
	V _{IN5, 6}	HCTR, LCTR	0.10		1.5	Vrms
Input voltage range	V _{IN7}	\overline{SD}	0		V _{DD}	V

Refer to the item "Relationship of set type, power source and current" for *1, *2, and *3.

Electrical Characteristics / under the allowable operating conditions

Parameter	Symbol	Conditions	Ratings			Unit
			min	typ	max	
Hysteresis width	V _H	RES, HOLD, INT	0.1V _{DD}			V
Reject pulse width	P _{REJ}	SNS			50	μs
Input high-level current	I _{IH1}	INT, HOLD, RES, \overline{SD} , SNS, REMO, STEREO, K5, K4, V _I =5.5V			30	μA
	I _{IH2}	XIN, V _I =V _{DD} =5.0V	2.0	5.0	15	μA
	I _{IH3}	FMIN, AMIN, HCTR, LCTR, V _I =V _{DD} =5.0V	4.0	10	30	μA
	I _{IH4}	K0, K1, K2, K3, V _I =V _{DD} =5.0V		50		μA
Input low-level current	I _{IL1}	V _I =V _{SS}			3.0	μA
	I _{IL2}	V _I =V _{SS}	2.0	5.0	15	μA
	I _{IL3}	V _I =V _{SS}	4.0	10	30	μA
Input floating voltage	V _{IF}	K0, K1, K2, K3			0.05V _{DD}	V
Pull-down resistance	R _{PD}	K0, K1, K2, K3	75	100	200	kΩ
Output OFF-state leakage current (high)	I _{OFFH1}	EO1, EO2, V _O =V _{DD}		0.01	10	nA
	I _{OFFH2}	T0 to T7, STB, AMUTE, PWROUT, NARROW, IFCNT, CLK, DO, CE, MUTE, MO/ST, SW1/VU, SW2/VD : V _O =V _{DD}			3.0	μA
	I _{OFFH3}	V _{OL} , FM, MW, LW, V _O =13V			5.0	μA
Output OFF-state leakage current (low)	I _{OFFL1}	EO1, EO2, V _O =V _{SS}		0.01	10	nA
	I _{OFFL2}	T0 to T7, STD, AMUTE, PWROUT, NARROW, IFCNT, CLK, DO, CE, MUTE, MO/ST, SW1/VU, SW2/VD			3.0	μA
Output high-level voltage	V _{OH1}	T0 to T7, I _O =1mA	V _{DD} -2.0	V _{DD} -1.0	V _{DD} -0.5	V
	V _{OH2}	CLK, DO, CE, MUTE, MO/ST, SW1/VU, SW2/VD : I _O =1mA	V _{DD} -1.0			V
	V _{OH3}	EO1, EO2 : I _O =500μA	V _{DD} -1.0			V
	V _{OH4}	XOUT : I _O =200μA	V _{DD} -1.0			V
	V _{OH5}	S1 to S28 : I _O =-0.1mA	V _{DD} -1.0			V
	V _{OH6}	NARROW, PWROUT, AMUTE, STB : I _O =5mA	V _{DD} -1.0			V
	V _{OH7}	COM1, COM2 : I _O =20μA	V _{DD} -0.7	V _{DD} -0.5	V _{DD} -0.35	V
Output low-level voltage	V _{OL1}	T0 to T7, I _O =1mA	0.5	1.0	2.0	V
	V _{OL2}	CLK, DO, CE, MUTE, MO/ST, SW1/VU, SW2/VD : I _O =1mA			1.0	V
	V _{OL3}	EO1, EO2 : I _O =500μA			1.0	V
	V _{OL4}	XOUT : I _O =200μA			1.0	V
	V _{OL5}	S1 to S28 : I _O =0.1mA			1.0	V
	V _{OL6}	NARROW, PWROUT, AMUTE, STB : I _O =5mA			1.0	V
	V _{OL7}	COM1, COM2 : I _O =20μA	0.35	0.5	0.7	V
	V _{OL8}	VOL, FM, MW, LW : I _O =5mA	0.75 (150Ω)		2.0 (400Ω)	V

Continued on next page.

LC7230-8272

Continued from preceding page.

Parameter	Symbol	Conditions	Ratings			Unit
			min	typ	max	
Output mid-level voltage	V_{M1}	COM1, COM2, $V_{DD}=5.0V$, $I_O=20\mu A$	2.0	2.5	3.0	V
Supply current	I_{DD1}	V_{DD1} , $f_{IN2}=130MHz$, PLL operating mode *4		15	25	mA
	I_{DD2}	V_{DD2} , CLOCK operating mode (PLL stopped, HOLD mode, Fig. 1) *5		2	3	mA
	I_{DD3}	$V_{DD}=5.5V$, OSC stopped, $T_a=25^\circ C$, *6 (Backup mode, Fig. 2)				5
$V_{DD}=2.5V$, OSC stopped, $T_a=25^\circ C$, (Backup mode, Fig. 2)					1	μA

Refer to the item “Relationship of set type, power source and current” for *4, *5, and *6.




Fig. 1 I_{DD2} at HOLD Mode




Fig. 2 I_{DD3} at Backup Mode

Unit (capacitance: F)

Set function grouping


Function	POWER SW		
	Tact switch usage	Mechanical switch usage	
Remote controller	○	×	○ Available × Not available
Timer and clock	○	×	
Electronic volume	○	○	
Function switch	○	○	

Relationship of set type, power source and current

Set		Status	When power is on		When power is off	When AC power is off
			Radio mode is on	Other than radio mode		
Power switch tact	With clock		V_{DD1} I_{DD1}	V_{DD2} I_{DD2}	V_{DD2} I_{DD2}	V_{DD3} I_{DD3}
	Without clock		V_{DD1} I_{DD1}	V_{DD2} I_{DD2}	V_{DD2} I_{DD2}	V_{DD3} I_{DD3}
Power switch mechanical	Without clock		V_{DD1} I_{DD1}	V_{DD2} I_{DD2}	V_{DD3} I_{DD3}	V_{DD3} I_{DD3}

Note) Refer to the Electrical characteristic reference for V_{DD1-3}

Key Matrix




Description of diode matrix (DIMRX)

0 : Without diode 1 : With diode

Name	Description	
B0 to B2	See the list of receiving frequency.	
SHIFT	0	Selection of MW, LW, SW without ()
	1	Selection of MW, LW, SW in ()
LW200	0	Selection of 100Hz for USA FM, absence of LW for others
	1	Selection of 200Hz for USA FM, presence of LW for others
IFCNT	0	Auto tuning without IF count (not applicable to LW)
	1	Auto tuning with IF count
TMR	0	Without timer CLOCK function
	1	With timer CLOCK function
AMAN	0	Manual tuning operation only
	1	Auto/manual tuning operation
C0 to C4	Setting of (C0, C1, C2, C3, C4)=(*)	
IFSHIFT	0	AM (MW, LW, SW) IF is set to 450kHz for all destinations
	1	AM (MW, LW) IF, except SW and 10kHz-MW, is set to 468kHz
COLON	0	Always lighted
	1	Flashing at a 1Hz rate
EVR	0	Electronic volume timer correction mode : available
	1	Electronic volume timer correction mode : not available

* See "Note" in Sample Application Circuit 4 (page 20).

Display



* ST displays when tuned to an FM station and STEREO is held LOW.


Display font 0 1 2 3 4 5 6 7 8 9

Key Description

- **CH1** to **CH8**
Key for writing/calling preset channels 1 to 16 (FM), 1 to 8 (AM). **CH1** key, **CH2** key correspond to channel 1/9, 2/10, respectively. For example, when you push **CH1** key and release it within 0.5 second, CH1 is called ; and when released in 0.5 second or more, CH9 is called.
When you push **ME** key, **F1** is displayed on the frequency display area and CH1 to 8 may be written for 5 seconds. If you push **ME** key once again within 5 seconds, **F2** is displayed and CH9 to 16 may be written. When you push any one key of **CH1** to **CH8** , your desired channel is written in a specified memory.

	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8	
8 channels (Mode 1)	1	2	3	4	5	6	7	8 F1
(Mode 2)	9	10	11	12	13	14	15	16 F2

- **ME**
 - ① Used to write a new channel in the preset memory. When you push this key once, **F1** (mode 1) is specified. When you push twice, **F2** (mode 2) is specified. When you push once again, **F1** returns.
The write enable mode is released automatically 5 seconds after this key pushed.
 - ② When you push this key together with **TIMER** key, the timer setting mode (time setting mode) is entered.
- **A/M** (AMAN DIMRX=1)
Key for selecting the auto/manual tuning mode. Each time you push this key, the mode is switched as auto → manual → auto **AUTO** display flashes at the auto mode.
- **TUP** **TDN**
 - ① Manual mode
Each time you push these keys, the channel No. goes up/down by one. When you hold these keys pushed for 500ms or more, the channel No. goes up/down at a 60ms/step rate.
 - ② Auto mode (AMAN DIMRX=1)
A broadcasting station is searched automatically in an up/down direction and a receiving frequency is held. If you hold this key pushed when the receiving frequency is reached, no auto stop occurs but a temporary stop (500ms) occurs. The searching rate is 60ms/step.
- **FM** **MW** **LW** **SW**
Key for band selection.
- **BAND**
Key for band selection. Each time you push this key, band switching occurs.




Continued on next page.

Continued from preceding page.

• **PS**

Key for preset scanning. When you push this key, the channel No. is changed in the order of increasing channel No. beginning with a channel No. currently displayed. If no channel No. is displayed, the channel No. is changed from CH1. If there is a channel that can be received during preset scanning (\overline{SD} ="L"), a sound is generated for 5 seconds and if there is no channel that can be received, the channel No. is displayed for 1 second with no sound generated and the channel No. is changed to the next one. The channel No. flashes at a 1Hz rate during preset scanning.



The preset scanning mode is released by pushing this key twice.

• **MO/ST** , **WD/NA** , **MUTE**

Key	Description	Display	Output
MO/ST	Effective at FM mode only For monaural/stereo selection	ST Lighted	L
		Unlighted	H
WD/NA	Effective at FM mode only For wide/narrow band selection	NAR Lighted	H
		Unlighted	L
MUTE	Effective in all modes with power ON. Unlighted and output "L" when power OFF is changed to power ON during the lighted state and when volume up or down is activated.	MUTE Lighted	H
		Unlighted	L

• **POWER**

Switch for turning ON/OFF the power supply of LC7230-8272-applied equipment. Each time you push this key, the level at output pin PWR OUT is switched as H → L → H The volume level at the power-ON mode is the same as for the previous power-OFF mode.

• **TIMER** (Causes turn-ON mode only. Not cause turn-OFF mode "ONCE" timer only.)

Key for providing time display at the timer setting mode, time setting mode or frequency display mode. When you push this key together with **ME** key, the timer setting mode is entered ; and when you release the two keys once and push them again simultaneously, the time setting mode is entered.

When you push **ME** key in the timer setting mode, the timer time setting is enabled with the timer time flashing and the standby mode is entered. **TDN** key and **TUP** key are used for hours setting and minutes setting, respectively. These settings are made in an up direction only. Each time you push **TDN** key or **TUP** key, the display contents increment by one. When you hold **TDN** key or **TUP** key pushed for 500ms or more, the display contents advance at a 4 hours/second rate or 8 minutes/second rate, respectively.

When you push **ME** key after completion of setting, a volume level at the timer turned-ON mode can be set. A digitally displayed volume level at this moment is the same as for the previously set value. The setting range is from -16dB to -80dB. The volume level at the initial mode is -50dB.


When you push **ME** key after completion of setting, the time display mode returns. When you wish to check the set time only at the timer setting mode, push **ME** key twice to return the mode to the timer display mode.

Next, in the time setting mode the time setting is enabled with the time display flashing. The setting method is the same as for the timer setting mode. When you push **ME** key after completion of setting, the second display is cleared to zero and the time display mode returns.

When power is turned ON at the initial mode, the time setting mode is entered.

When you push a function key during timer setting or time setting, such mode is released.

Example of volume display ← -50dB display.




Continued on next page.

LC7230-8272

- **SLEEP**

Key for sleep time setting. When you push this key in the **SLEEP** display OFF state, the **SLEEP** display is turned ON and $\frac{60}{10}$ (minutes) is displayed. Each time you push this key, $\frac{60}{10}$ decrements in units of 10 minutes. When $\frac{60}{10}$ is reached, **SLEEP** display is turned OFF and the sleep time setting mode is released. The previous mode returns 5 seconds after a sleep time is set to a specified value (**SLEEP** key is released).



When you push the **SLEEP** key while in clock display or frequency display, the remaining sleep time is displayed. 5 seconds after releasing the key the previous status will return.

- **TIMER ON**

Each time you push this key, **TIMER** display is turned ON/OFF. When turned ON, the timer operation is carried out ; and when turned OFF, no timer operation is carried out.

- **TUNER**

When you push this key in the state where the CD, PHONO, TAPE, AUX functions are provided, the function is switched to TUNER and the frequency display is provided.

- **CD**

When you push this key in the state where the PHONO, TAPE, AUX, TUNER functions are provided, data is transferred to the LC7821 (N), the function is switched to CD and **CD** display is provided. You can also use this key for the CD power supply control signal and LED function display.

- **PHONO**

When you push this key in the state where the TAPE, AUX, TUNER, CD functions are provided, data is transferred to the LC7821 (N), MLC74HC375, the function is switched to **PHONO** display is provided.

- **TAPE**

When you push this key in the state where the AUX, TUNER, CD PHONO functions are provided, data is transferred to the LC7821 (N), MLC74HC375, the function is switched to **TAPE** , and TAPE display is provided.

- **AUX**

When you push this key in the state where the TUNER, CD PHONO functions provided, data is transferred to the LC7821 (N), MLC74HC375, the function is switched to AUX and **AUX** display is provided.

- **VUP** **VDN**

Keys for increasing/decreasing the electronic volume control level. Each time you push these keys, the level goes up/down by 1dB. When you hold these keys pushed for 500ms or more, the level goes up/down at a 150ms/dB rate. The level display for the LB1417 is shown below.

Level	1st Dot	2nd Dot	3rd Dot	4th Dot	5th Dot	6th Dot	7th Dot
Attenuation	-80dB	-52dB	-38dB	-26dB	-18dB	-10dB	-4dB

For specifications with no SW band, the volume increase/decrease signal is delivered at the SW1, 2 pins.


Remote Control

(1) The keys other than shown below are the same as for LC7230-8272-applied audio equipment.

Key Name	Description	Pin	Output Waveform
PLAY/PAUSE	PLAY/PAUSE key for CD	NARROW	Single pulse
STOP	STOP key for CD	IFCNT	
NEXT	NEXT key for CD	MW	Continuous pulse
BACK	BACK key for CD	LW	
CHUP	Each time you push this key, the channel No. goes up by one. When you hold this key pushed for 0.7 second or more, the channel No. is switched every 0.4 second. If there is no channel No. Present, the channel No. starts with CH1.		

(2) Remote control reception interdiction period.


① After power on, this unit does not receive the remote control function for the period in which the volume value returns from $-\infty$ to the original value. (When DIMRX of TMR is 1.)




② After turning the power on, unable to receive for 2 seconds. (When DIMRX of TMR is 0)

Timing Description


(1) Auto up/down mode



(2) Manual




(3) Power ON mode (See Sample Power Supply Connection (1).) (Including the timer, sleep timer modes)




- (Note) 1. Data of $-\infty$ is sent to the LC7535 immediately before power is turned OFF.
 2. Data of $-\infty$ is sent to the LC7535 immediately after power is turned ON.
 3. When the SNS pin is brought to H-level after power is turned ON, the original volume level returns at a 38ms/dB rate.

(4) Audio mute (AMUTE)


- ① Key chattering eliminating time (approximately 40ms)
 - ② Audio pre-mute time (approximately 50ms)
 - ③ Interstation wait and data transfer to PLL (20ms to 80ms)
 - ④ Audio post-mute time
 - ⑥ Processing required for the LC7535, LC7821 (N), MLC74HC375, etc. (approximately 5ms)
- a. Band select mode, present channel read mode




b. Manual up/down mode




c. Auto up/down mode




d. PS mode




e. Function select mode (also applicable to FMUTE of the MLC74HC375 (N))




f. Initial power-ON mode



(5) FMUTE (MUTE for Switching Functions)



Connection with Peripheral ICs



* Note :

CD output and NEXT (MW), BACK (LW) output when CD function is selected is changed as following. At this time in order to prevent CD error of point (A), it is necessary to delay CD output.


Pin Description

Pin Name	Pin No.	Description	Active	I/O	I/O configuration	
XIN	1	4.5MHz crystal oscillation pins.	-	I	-	
XOUT	80			O		
TEST1	2	Must be connected to V _{SS} .	-	I	-	
TEST2	79					
REMO	3	Remote control signal input pin. Used with INT pin. When no remote control is not in use, pulled up to V _{DD} through a resistor.	L	I	A	
STEREO	4	When the stereo signal is brought to L-level, "ST" LCD indicator light goes ON.	L	I	A	
VOL	7	The LB1417 is connected to this pin to provide the electronic volume control level display.	-	O	C	
FM	8	Used to select the power supply for each band.	L	O	C	
MW	9					CD NEXT signal output
LW	10					CD BACK signal output
SW1/VU	11	Spec. With no SW band	H	O	B	
SW2/VD	12					"H" output only when VUP key is pushed "H" output only when VDN key is pushed
MO/ST	13	Output pin for monaural "H"/stereo "L" selection	H	O	B	
MUTE	14	L-level at power-ON mode. Each time you push [MUTE] key at the power-ON mode, "H"/"L" toggle operation is carried out.	H	O	B	
CE	15	Serial data line of the LC7535, LC7821 (N).	H	O	B	
DO	16					
CLK	17					
IFCNT	18	Signal to output the IF signal. STOP signal output at the CD mode.	H	O	B	
NARROW	19	Pin for IF narrow band "H"/wide band "L". PLAY/PAUSE signal output at the CD mode.	H	O	B	
PWR OUT	20	Power control pin.	H	O	B	
AMUTE	21	Audio muting pin.	H	O	B	
STB	22	Pin for strobe of data to the MLC74HC375. Connected to "CL".	H	O	B	


Continued on next page.

LC7230-8272

Continued from preceding page.

Pin Name	Pin No.	Description	Active	I/O	I/O configuration
T7	23	Data transfer to the ML74HC375	H	O	B
T6	24	Data transfer to the ML74HC375			
T5	25	Data transfer to the ML74HC375			
T4	26	Data transfer to the ML74HC375			
T3 T2 T1 T0	27 28 29 30	Key scan output signal.			
K3 K2 K1 K0	32 33 34 35	Key-in signal.	H	I	A
K4 K5	6 5	Diode matrix input signal.	H	I	A
S1 to S28	63 to 36	LCD segment driver pins.	-	O	B
COM1 COM2	65 64	LCD common driver pins.	-	O	D
HOLD	67	When brought to L-level, the backup mode is entered. A chattering of approximately 20ms is eliminated.	L	I	A
\overline{SD}	69	Signal to inform that a channel is received during auto tuning.	L	I	F
HCTR	70	FM IF signal input pin.	-	I	A
LCTR	71	AM IF signal input pin.	-	I	A
SNS	72	When brought to H-level, data is sent to the LC7821 (N), LC7535, MLC74HC375, LB1417. A chattering of approximately 20ms is eliminated.	H	I	A
FMIN	74	Local OSC input from FM VCO.	-	I	A
AMIN	75	Local OSC input from AM VCO.	-	I	A
EO1, 2	76 77	Phase comparator output signal.	-	O	E
\overline{INT}	66	Remote control signal input pin. Used with REMO pin.		I	A
V _{DD}	31 73	Power supply pin. Connected to +5V.	-	-	-
V _{SS}	76	Power supply pin. Connected to GND.	-	-	-
RES	68	Must be connected to V _{DD} .	-	-	-

Pin input/output configuration




Band Power Supply Select Signal

Band \ Pin	FM	MW	LW	SW1	SW2
FM	L	H	-	-	-
MW	H	L	L	L	L
LW	H	L	H	L	L
SW1	H	L	H	H	L
SW2	H	L	H	H	H

Sample Power Supply Connections


(1) TMR DIMRX "0" "1" function possible.

Use tact switch for power switch (when using the remote control, with timer, etc.)



(2) TMR DIMRX "0" use possible, "1" use not possible.

Use mechanical switch for power switch, (when not using Remote Control, with Timer)



Initial Mode

- Function : TUNER
- Clock 12hr : 12 : 00
- Clock 24hr : 0 : 00 } Flashing Timer set value : 10 : 00
- Band : FM
- A/M : Manual (AMAN=1)
- Timer, sleep timer : Timer OFF
- Preset channel : None
- ME : OFF
- MO/ST : Stereo MO/ST pin="L"
- WD/NA : Wide WD/NA pin="L"
- Volume : -50dB
- Volume level : -50dB
- at timer mode
- Muting output : L-level
- PWROUT : L-level

LC7230-8272

Tracking Point

The following frequencies are loaded in each preset memory at the initial power-ON mode.


[FM : MHz, AM : kHz]

Area	Band	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8	Diode Matrix B ₂ B ₁ B ₀
JAPAN	FM	76.0	78.6	83.0	86.6	90.0	76.0	76.0	76.0	1 0 0
	MW	531	603	999	1404	1611 (1629)	531	531	531	
USA	FM	87.9	90.1	98.1	106.1	107.9	87.9	87.9	87.9	0 0 0 1 1 1
	MW	530	600	1000	1400	1610 (1720)	530	530	530	0 0 0
	MW	522	603	999	1404	1611 (1719)	522	522	522	1 1 1
EUROPE	FM	87.5	90.0	98.0	106.0	108.0	87.5	87.5	87.5	0 0 1 0 1 0 0 1 1
	MW/LW	531 (522)	603	999	1404	1602 (1611)	153 (146)	270	281 (290)	0 1 0
	MW/SW	↑	↑	↑	↑	↑	5800	9500	13500	0 1 0
	MW/SW	↑	↑	↑	↑	↑	5200	9500	13500	0 1 1
	MW/LW/SW	↑	↑	↑	↑	↑	153 (146)	270	281 (290)	0 1 0 0 1 1
S.AFRICA	FM	87.5	90.0	98.0	106.0	108.0	87.5	87.5	87.5	1 1 0 1 0 1
	MW/LW	531 (522)	603	999	1404	1602 (1611)	153 (146)	270	281 (290)	1 1 0
	MW/SW	↑	↑	↑	↑	↑	5800	9500	13500	1 0 1
	MW/LW/SW	↑	↑	↑	↑	↑	153 (146)	270	281 (290)	


Note 1) () : Value when diode matrix "SHIFT" is selected.

2) CH9 to CH16 are loaded with low band edge at the FM mode.


Waveforms on Segments, Common Pins



(1) Connection of Segments on Panel




(2) Connection of Common Pins on Panel




LC7230-8272

Sample Application Circuit 2 (With remote controller, timer, function switches and electric volume)
Use tact switch for power switch



LC7230-8272

Sample Application Circuit 3 (With function switches and electric volume) Use mechanical switch for power switch




Note) 1. Adjust TP so that becomes 4.375V is obtained.
2. ■ pin must be left open.

Unit (capacitance: F)

LC7230-8272

Sample Application Circuit 4



Note) The above connection of C0-C5 is an experimental connection only.
 For mass-production, other specifications authorized by SANYO Electric Co., Ltd., are required.

No.	KEY	No.	KEY	No.	KEY	No.	KEY
0	CH1	8	FM	16	PLAY / PAUSE	24	BAND
1	CH2	9	MW	17	PS	25	POWER
2	CH3	10	LW	18	MO/ST	26	TIMER ON
3	CH4	11	SW	19	CHUP	27	TUNER
4	CH5	12	NEXT	20	TIMER	28	CD
5	CH6	13	BACK	21	SLEEP	29	PHONO
6	CH7	14	VUP	22	STOP	30	TAPE
7	CH8	15	VDN	23	MUTE	31	AUX

Custom Code of the LC7461M-8103


The LC7461M-8103 is a remote control signal transmission IC to be used in conjunction with the LC7230-8272.

The custom code of the LC7461M is such that the 7 bits are fixed by the internal metal mask and the remaining 6 bits are set using the IC pins.

Custom code 0100H is available for evaluation. When performing evaluation, the code of the LC7461M-8103, LC7230-8272 must be set to this code value.

When evaluation is acceptable, a custom code to be used must be assigned before mass production of equipment and your draft on remote control IC should be submitted.

How to set code 0100H for evaluation.



Set C0 to C4 of the LC7230-8272 to 0.

When a custom code for mass production is assigned, C0 to C4 are set to 1 (connected to V_{DD}) or 0 (connected to V_{SS}) according to the specified code.

Note) A code of the LC7230-8272 is set according to 1 (with diode) and 0 (without diode).

- Specifications of any and all SANYO products described or contained herein stipulate the performance, characteristics, and functions of the described products in the independent state, and are not guarantees of the performance, characteristics, and functions of the described products as mounted in the customer's products or equipment. To verify symptoms and states that cannot be evaluated in an independent device, the customer should always evaluate and test devices mounted in the customer's products or equipment.
- SANYO Electric Co., Ltd. strives to supply high-quality high-reliability products. However, any and all semiconductor products fail with some probability. It is possible that these probabilistic failures could give rise to accidents or events that could endanger human lives, that could give rise to smoke or fire, or that could cause damage to other property. When designing equipment, adopt safety measures so that these kinds of accidents or events cannot occur. Such measures include but are not limited to protective circuits and error prevention circuits for safe design, redundant design, and structural design.
- In the event that any or all SANYO products (including technical data, services) described or contained herein are controlled under any of applicable local export control laws and regulations, such products must not be exported without obtaining the export license from the authorities concerned in accordance with the above law.
- No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or any information storage or retrieval system, or otherwise, without the prior written permission of SANYO Electric Co., Ltd.
- Any and all information described or contained herein are subject to change without notice due to product/technology improvement, etc. When designing equipment, refer to the "Delivery Specification" for the SANYO product that you intend to use.
- Information (including circuit diagrams and circuit parameters) herein is for example only ; it is not guaranteed for volume production. SANYO believes information herein is accurate and reliable, but no guarantees are made or implied regarding its use or any infringements of intellectual property rights or other rights of third parties.

This catalog provides information as of October, 2001. Specifications and information herein are subject to change without notice.